

Cleaning :

To maintain the performance and extend the lifespan of your device, regular cleaning is essential. Follow these steps for optimal results:

- Cooling Period: Ensure the device has not been in use for at least 10 minutes before you begin cleaning.
- Empty the chamber completely.
- Use a Q-tip to gently clean the chamber in a circular motion.
- Wipe the mouthpiece with a damp cloth.

Caution:

Keep the device away from any environment involving strong acids, alkaline, combustible materials, water, or any other liquids.

Do not keep in hot cars or store above the room temperature of 74F.

Do not use damaged batteries. If the battery casing is damaged, discontinue use and safely recycle the battery.

Do not use the battery if contacts become exposed to solid or liquid matter.

Shorts can result in fire or an explosion of a battery.

Do not touch coils when hot. Severe burns can result in.

Do not touch hot material. Severe burns can result in.

If the device gets too hot in use, please stop using it for a while.

Not for use with nicotine or other nicotine salt products.

Not an ENDS device.

Disclaimers:

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breastfeeding should not use this product.

The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions.

The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.



ORBIT 2.0
Instruction Manual

Specification:

Size: $\Phi 24 \times 130.5 \text{mm}$
Coil Resistance: 0.4Ω
Voltage Range: 2.8V-3.8V
Preheat (2.8V): 10 seconds
Safety Cutoff: 15 seconds
Up To: 25 Puffs (3.8V)
Battery Capacity: 1400mAh
Charging Type: 5V/1A Type-C
Charging Time: 2.0h

Package Content:

- 1x Orbit 2.0 Device
- 1x Orbit Quartz Cup
- 1x Glass Cover
- 1x Pick Tool
- 4x Q-tip
- 1x Instruction Manual
- 1x Type-C Charging Cable
- 12x Extra Quartz Terp Balls
- 1x Silicone Mouthpiece Cover

How To Use:



1. Turn on/off: Quickly tap the power button 5 times within 2 seconds.
2. Pull out the glass cover, fill the concentrate into the quartz cup and then put the glass cover back on.
3. 2.8V 10 Sec Preheat: Quick click the power button 2 times.
4. Voltage Adjustment: click power button 3 times to enter voltage setting mode, click once to increase by 0.1V, press and hold for rapid increase.
5. Vape: Press and hold the power button.
6. Puff Reset: quickly click the power button 7 times.
7. Charging: Type-C port. Fast charging not supported. Charging time around 2.0 hour.

Protection:

1. Auto Shut Down: Auto shut down after 0.5 Hour.
2. High temperature protection.
3. Over charge protection.

Yoican 3.2v	Power On.
TAKE CARE	Power OFF.
2.0Ω	Coil connected, shows coils resistance.
TOO HOT	High Temperature Protection.
OVER TIME	Over time.
NO ATOMIZER	No atomizer connected, quartz cup defects.
SHORTED	Short circuit.
LOW BATTERY	Please charge the device.